


IR. Driveway Intruder Alarm **INSTRUCTION SHEET**



The alarm is designed with an integral power supply to run off 240V Mains. (Battery version, only to special order, 12v DC)

There are three small Knobs on the front panel. Please note :- the minimum setting is fully anticlockwise.

- A) Buzzer Time. Adjustment between $\frac{1}{2}$ second and 15 seconds. (left hand knob)
- B) Delay before siren activation. Adjustment between 1 second and 2 minutes.
- C) On Time / siren activation. Adjustment between 1 second and 3 minutes

The Buzzer time is completely independent of the other two. Upto two extra buzzers can be connected to two terminals in the box. (See diagram page 3) These are available from Sutcliffe Electronics.

Please Note :- Set the delay time longer than the buzzer time to prevent the unit from retriggering spuriously when the buzzer stops.

WIRING (see diagram)

The Sender and receiver boxes both have two screw terminals. The control box has two 'Beam' terminals on the left hand side, away from the siren and buzzer terminals. These only have 12V on them. **The 4 terminals under the guard, are not for connecting the beam.** Wire the Cable pair to the beam terminals, and on to the first of the beam boxes. Control box, sender and receiver are wired in parallel. The terminal pairs in the sender and receiver boxes have no polarity, just wire a brown and a blue to each. The sender and receiver boxes can be wired independently, or from one to the other, which ever is the most convenient. *Accessory power supplies are available for SENDER ONLY to be connected to a separate mains supply. The receiver/s must be wired to the control box.*

Upto six mixed modules can be wired to the control box, thus three senders and three receivers, or six receivers only etc. If not working in pairs, an Accessory power supply will be required for the senders. **Make sure the cable is not blocking the optical area between lense and detector, or lense and sender diode, at the rear of the housings.**

We suggest it is advisable to strip off the outer insulation, such that only the inner blue and brown wires go through the hole. This prevents capillary action allowing extra moisture into the beam boxes if the outer cable has become damaged. It is also much easier to wire.

To prevent insects from entering the boxes, use 'blutak' or equivalent, to seal the hole round the wires.

MOUNTING (see page 4)

Mount with the flat lid down, to ensure the units are weatherproof. **Do not seal the boxes**, this causes corrosion.

Please Note, Some people have used 'Silicone Sealer' to mount or seal the boxes. This usually gives off **Acetic acid fumes** as it cures, which will corrode the circuit boards causing the intruder alarm to fail.

When mounting the sender and receiver boxes, use one of the four blind holes on the corner of the boxes to fix the bracket with the supplied screw and rubber washer. **Do not drill extra holes for mounting, or connecting cable.** The mounting brackets supplied are a simple right angle. One side is fixed to the flat top of the housing, and the other to a vertical. The beam can then be swivelled left and right and up and down. The Rubber washers are supplied to provide resistance to movement. Fit one between the bracket and the box, and the other between the bracket and the mounting point. It is then possible to adjust the beams without undoing them. (See diagram Page 4)

The central hole in the bottom is for ventilation only, please do not use for the cable.

The other hole in the bottom is for the cable.

Please use the screwdriver supplied for the terminals. It is very easy to over tighten the screws if a larger driver is used.

It is better to mount the boxes **inside** posts than on them. This reduces the chance of someone damaging them. The alarm will go off once, but you have lost your security. Also the boxes will not be so obvious, the system is most efficient if mounted covertly.

SETTING UP

Connect the boxes as per diagram, close the lids. You will note a red light next to the lens of the receiver. When the beam is **NEAR** alignment this will go out, and remain so except when the beam is broken. When fitting a long beam, it can help to use a fishing line to get the angles. The focal point is not always exactly dead centre, so a laser pointer will not always give an exact result.

To ensure the beam is correctly centred, sender on receiver, receiver on sender. First adjust the receiver **UP DOWN LEFT RIGHT** to position it centred on the beam. (The middle of the dead area when the red light does not show) Then go to the sender, you can see the red light on the receiver, by looking down the beam. Adjust the sender in the same way. **UP DOWN LEFT RIGHT**. *If you are finding it difficult to see the red light, it is easier to see if this is done at dusk.* Then use a piece of card to partly cover the **receiver** lens. The red light should not come on until the lens is covered to within $\frac{1}{4}$ " / 6mm or less of the far side in any / all directions. Ie most of the lens covered. (At night this could be as little as $\frac{1}{8}$ " / 3mm) **UP DOWN LEFT RIGHT**. **Please note the beam is not set up until this is possible.** Time spent getting the beam right will save false triggering later. Do not assume that because you have used a laser pointer to line up the beam, that it will be correct.


Final setting up is best not done at night, recheck the receiver during daylight. When you are satisfied, cover the red light with a small piece of insulating tape to hide it.

The sender and receivers are fitted with lens hoods and louvers, this is to protect against low sun causing false alarms by swamping the receiver. It also protects against frost forming on the lenses which destroys the focus. When planning the mounting position, mount the receiver pointing away from the light. In the UK, if the beam is set North South, it is best to have the receiver pointing North. Also try not to mount directly East West into the rising or setting sun. There is no reason why the beam should not be mounted diagonally.

Please try out the alarm indoors before fitting in the final position. It is better to make your mistakes on a dry run, not outside in the rain. Make sure the box lids are **on**, the units are affected by lights.

BIRD IMMUNITY PERIOD

The immunity period which limits the effect of birds breaking the beam, (set to roughly 1/10 sec) is adjustable. **We do not expect that you would have to alter it.** Set to minimum the alarm would be triggered by most birds, and at maximum it is easy to get through the beam without triggering it. The adjuster is the preset in the bottom of the **RECEIVER**, (the box with the red light) and the setting can be changed without taking the boards out. Anticlockwise for longer, Clockwise for shorter. (Use the screwdriver supplied with the kit)



PLEASE NOTE:- The preset in the SENDER must not be touched. It would seriously reduce the sensitivity of the system, and require the return of the module to us for resetting.

Sutcliffe Electronics offer help on the telephone during normal working hours, if problems occur during setting up

Tel 0560 1560499 or 01233 634191 help@sutcliffeelectronics.co.uk

Please make sure these Instructions are kept



DIACON4 CONTROL BOX DIAGRAM

Including siren wiring diagram. There is no relay switch in this module


© Sutcliffe Electronics 06/2009

Turn Knobs Fully anticlockwise for minimum time settings

Buzzer Delay On
 time Time



Please note polarity is marked on the power Supply, and which Way round the Terminals are wired:-
J7(-) & J8(+)
J9(+) & J10(-)



To switch off siren, either put a switch in the Lead to J8 or Plug the Power supply into a Switched socket.

Please note:- mains electricity is only connected Via the plug pins on the back.

- J4 Beam +
- J5 Beam -
- J6 Beam (only for 3 wire system)

- J7 Siren Power Supply --
- J8 Siren Power Supply +
- J9 Siren +
- J10 Siren -
- J13 Extra buzzer - (black)
- J14 Extra buzzer + (red)

IMPORTANT

The wires from the beam boxes must only be connected to the beam terminals J4 & J5. It does not matter which way round they are connected. The beam boxes are designed to work either way round.

We supply a screwdriver with your kit for use with the small terminals in the boxes



To expose the siren terminals for wiring, unscrew the two posidrive screws which hold the terminal guard. Wire the unit to match your chosen configuration, and refit the guard. Use the cable clamp to hold the cables. Wiring diagram above.


PLEASE NOTE

- 1) We suggest that only siren systems that are approved by Sutcliffe Electronics are used. Any damage caused by the addition of inappropriate devices is not covered under the guarantee.
- 2) The terminal guard holds the circuit board in position.

DO NOT PLUG UNIT INTO THE MAINS WITH THE GUARD UNFITTED.

POSTSCRIPT

The units are designed to run continuously. Condensation will form in the sender and receiver, destroying them if regularly switched on and off and allowed to cool. When the system is not required, just turn the buzzer to minimum. Any external sounder can be isolated separately.




Mount the beam boxes inside rather than on a post. Hollow posts can be made from four planks nailed together

Mounting Holes


There are four blind holes in the top, one of which is used for the mounting bracket. (Screw supplied) We do not specify which, since the best position depends on where and on what the beam is mounted. Please note how the rubber washers are used.

For maximum stability, please mount using the front holes.



Mounting bracket

It is recommended that the box is mounted from the side and not from the back, otherwise it will not be possible to adjust the box to point up and down. Note the overhang is to allow left/right movement, and where the Rubber washers are fitted.



Cable & ventilation holes

The Beam boxes have a central hole drilled in the bottom. This is covered with a filter material, and is designed to allow the units to breathe. The hole round the cable should be blocked with a little "bluetak" to prevent insects from getting in. The correct way round for the bases is indicated by the **LENS** label.-

Cable

To prevent capillary action on the cable outer drawing water into the boxes and causing corrosion, strip the outer cable longer, such that it is only the blue and brown wires which enter the boxes. This may look more untidy, but will improve the reliability of the system

Driveway Intruder Alarm check list

We have written and rewritten the instruction sheets for the 20 plus years this product has been in production. If you have followed the suggested methods of mounting and wiring, your Driveway alarm should give you good service.

This is not an exhaustive list but should help with the usual questions received.

- 1 The beam wired into the two terminals on the left hand side of the control box.
- 2 It is usual for both sender and receiver to be powered by the 12 Volt from the Control Box, but where they are coupled together does not matter. If there is an Accessory Power Supply for the Sender. Make sure it is the **Sender** it is wired to, not the receiver which must be connected to the Control box.
- 3 **It does not usually help to try to set up the beam with a laser pointer.** It can help however to use a television remote control to find out if the receiver is pointing off line. Walk slowly back, following the sensitive area, you will soon find if it is pointing up into the air, or down the the ground. This is particularly valid for 20 and 40 metre beams. 2 degrees out at 40 metres is a long way.
- 4 The hole in the centre of both sender and receiver bases, is not to be used. It is only for ventilation.
- 5 The other hole pre drilled, is for the cable. If the base is positioned as indicated, it will route the cable out of harms way, such that it has little effect on the quality of the projected / received beam. Please take particular note of this point as it is difficult to explain over the phone that this is the only reason that false alarms are occurring.
- 6 The beam is centred with the aid of the red light on the receiver, there is no need to be able to hear the buzzer in the control box.
- 7 When correctly set up, it is possible to almost completely cover the receiver lens without the red light showing. It will be the same from which ever direction the lens is covered. Though the receiver may be adjusted perfectly, the job is not finished until the sender is also centred. No one wants false alarms. We regularly check 10m sets at 30m to prove that they will work correctly, so there should be no problem setting them up at 10m.
- 8 There is no need to drill the boxes for the mounting bracket. The screw supplied fits the blind holes in the boxes. (spare sets of screws and rubber washers are available)
- 9 Please use the rubber washers (see diagram). We have learnt from practical experience that they prevent the beam from moving with time. (False alarms) If you have Lost them, We can supply replacements.
- 10 A beam which is out of true or has the cable shading the sender or receiver diodes will be affected by daylight, or at least sunlight. Comment "It works perfectly all night, but false alarms all day" Answer, "Please make sure the cables are not in the optical area, and realign your beam"
- 11 If the receiver has power, but is not receiving anything, the red light will glow continuously. You can prove whether it is working by using a television remote control. You should be able to get some effect up to about 5m. If it will not work with the television remote, there is a fault. This could be a damaged cable, or the system itself. Prove it is not the cable by doing a bench test. (2 or 3 metres apart)
- 12 40m beams only.--- Make sure both senders are equal, using a card, covering each lens in turn, and then checking how far the second lens can be covered.
- 13 If you are fitting the system for someone else, involve them with the setting up. There is nothing worse than being called back to move the receiver by 4 mm, because the post has shifted slightly. Your customer will be much happier.
- 14 A quarter of an hour at the end of the job, spent making sure the beam is as good as you can get it, will save a lot of heartbreak later.
- 15 If you are joining two cables not in the boxes, Use ordinary screw connectors, then smother with grease, and put them a plastic bottle to keep the rain and moisture out. Make sure you have not left one strand of wire shorting it out. If required, the bottle can be buried upside down [nozzle down], such that water cannot get to the joint.
- 16 False alarms, but only when it is windy and or raining. ---- Something has grown up into the beam path. (In my case nettles)
- 17 False alarms, but only after rain. Gets better in dry periods. ---- Damaged cable or joint in the cable.
- 18 Sender does not seem to be working but receiver is. ---- Damaged cable between sender and receiver under the road.
- 19 Sometimes the control box continuously retriggers when the delay time is set very short. Cure:-Set the delay time to be longer than the buzzer time even if you are not using a siren
- 20 A thermal fuse is in the control box, which should prevent the unit from burning out, if the output to the beam is shorted. Remove the short, allow the control box to cool down, try again.